

REMOTE ALARM™ - MODEL RA

Audible and Visual Alarm Component



APPLICATIONS:

- *Medical*
- *Process Control*
- *Reverse Osmosis*
- *Waste Treatment*
- *Conductivity / TDS*
- *Resistivity*
- *pH/ORP*
- *And many more ...*

FEATURES:

- *A loud audible alarm, 75 db at 2 ft./610 mm*
- *USER adjustable time delay of 0.1 to 10 minutes*
- *Simple push button switch temporarily silences alarm*
- *Bright RED LED remains clearly visible while alarm is silenced*
- *Operates on safe 24 VDC*
- *Case is made of rugged ABS plastic*
- *Compact size only 4.75 L x 2.56 W x 1.56 H in. / 121 L x 65 W x 40 H mm*
- *Wire lengths of 500 ft./152 meters have been tested with no adverse effects*
- *Screw or adhesive mounting option*

OVERVIEW:

The Myron L® Company's accessory for our Monitor/controller line is the Remote Alarm™. This remotely mounted AUDIBLE and VISUAL alarm connects to any Myron L® Company controller, or brand "X" controller with dry contacts (requires 24 VDC). When activated by the controller the Remote Alarm will provide both an audible and a visual alert at a location other than at the controller.

A mute button will silence the Piezo alarm for up to 10 minutes while the LED remains illuminated. After the preset time the Piezo alarm will again sound, this will repeat until the water quality is corrected. Thus allowing servicing of the system under control, while still acting as a reminder if the problem has not been corrected.

EASY INSTALLATION:

1. Only 2 wires to connect from the controller to the RA.
2. Set the time.
3. Mount on the wall or on the bench.

ORDERING INFORMATION:

Model RA: Order #RA

Optional: 200 ft./61 meters of 2 conductor insulated wire: Order #RAW200

* Fixed timer available on SPECIAL order: Contact us with set time, and quantity for price quote.

LIMITED WARRANTY

The Myron L Remote Alarms have a Two (2) Year Limited Warranty. Warranty is limited to the repair or replacement of the Remote Alarm instrument only, at our discretion. The Myron L® Company assumes no other responsibility or liability.

2450 Impala Drive
Carlsbad, CA 92010-7226 USA
Tel: +1-760-438-2021
Fax: +1-800-869-7668 / +1-760-931-9189
www.myronl.com

Built On Trust. Founded in 1957, the Myron L® Company is one of the world's leading manufacturers of water quality instruments. Because of our commitment to product improvement, changes in design and specifications are possible. You have our assurance any changes will be guided by our product philosophy: accuracy, reliability, and simplicity.

MYRON L®
COMPANY
Water Quality Instrumentation
Accuracy • Reliability • Simplicity