

uDOCK™ Accessory Package

IR Data Transfer Port for the Ultrameter II™



Transfer Data stored in Ultrameter II™ and PoolPRO™ handheld instruments to PC application via IR port

Reduce Data logging time/errors

Share saved water sample data

Lose the clipboard and still easily comply with record-keeping requirements

PRODUCT HIGHLIGHTS

- Transfer Data with accuracy, reliability and simplicity using our new uDock™ Model U2CI through the instrument's IR port
- Easy to install software from CD or www.myronl.com
- The uDock application will operate on Windows XP and Vista*; and Macintosh OS9.2 and OSX**
- Automatic organization of data



(record number, type of measurement, value and unit measurement, solution, temperature, date and time stamp).

- Exports to Office software (Word*, Excel*, Works*...etc) using universal formatting (.CSV) files
- Control your Ultrameter II™ and PoolPRO™ time and date setting through our uDock software.
- Clear instrument memory through our uDock software
- Self powered by USB port

(No batteries or external power supply needed)

For further information, please visit www.myronl.com or contact us at +1-760-438-2021.

*™ Microsoft **™ Macintosh

LIMITED WARRANTY

All Myron L uDocks have a Two Year Limited Warranty. Warranty is limited to the repair or replacement of the uDock only, at our discretion. The Myron L Company assumes no other responsibility or liability.

record #	measurement	value	unit	solution	temp.	date	time
1	COND	782.8	uS	KCl	30.5	2006-08-14	12:49:52
2	COND	776.3	uS	KCl	26.7	2006-08-14	12:49:06
3	COND	71.05	uS	KCl	22.5	2006-08-14	12:51:09
4	COND	698.5	uS	KCl	22.4	2006-08-14	12:51:40
5	COND	6809	uS	KCl	22.4	2006-08-14	12:52:09
6	COND	730.7	uS	KCl	22.4	2006-08-14	12:52:48
7	COND	1418	uS	KCl	22.4	2006-08-14	12:53:18
8	COND	1432	uS	KCl	22.2	2006-08-14	12:54:19
9	COND	0.65	uS	KCl	22.3	2006-08-14	12:56:06
10	COND	774.0	uS	KCl	28.2	2006-08-14	13:04:22

Myron L uDock software screen displaying 10 conductivity records



uDock™ in Action. U2CIP includes uDock, USB cable, and application software for your Mac or PC

2450 Impala Drive
 Carlsbad, CA 92010-7226 USA
 Tel: +1-760-438-2021
 Fax: +1-800-869-7668 / +1-760-931-9189
www.myronl.com

Built On Trust. Founded in 1957, the Myron L Company is one of the world's leading manufacturers of water quality instruments. Because of our commitment to product improvement, changes in design and specifications are possible. You have our assurance any changes will be guided by our product philosophy: accuracy, reliability, and simplicity.

MYRON L COMPANY
 Water Quality Instrumentation
 Accuracy • Reliability • Simplicity