

# bluDock™ Accessory Package



Bluetooth® Wireless Data Transfer for Ultrameter II™ Instruments



**Model: BLUDOCK**  
bluDock™ Accessory Package  
includes bluDock™, Macintosh/PC  
application software and dongle  
for downloading data and printed  
instructions.

## Wireless Data Transfer



**REDUCE DATA LOGGING ERRORS**

**REDUCE DATA LOGGING TIME**

**SHARE SAVED WATER SAMPLE DATA**

**LOSE THE CLIPBOARD AND STILL  
EASILY COMPLY WITH RECORD-  
KEEPING REQUIREMENTS**

## WIRELESS BENEFITS

The bluDock™ accessory package is an integrated data solution for your record-keeping requirements, eliminating the need for additional hardware, wires and hassle. Because the user never touches the data, there is little opportunity for data tampering and human error. Package includes everything you need to transfer data wirelessly from any Ultrameter II™, POOLPRO™ or DIGITAL DIALYSATE METER™ to your personal computer via Bluetooth®\* technology. bluDock software has an easy to use interface with user intuitive functions for storing, sorting and exporting data.

## PRODUCT HIGHLIGHTS

- Automatically organizes data by record number; measurement parameter, value and units; solution mode; temperature; date; and time.
- Export to Office\*\* software (Word\*\*, Excel\*\*, Works\*\*, etc.) using universal formatting (.csv) files.
- Catalog data by source by assigning instrument name.
- Set instrument time and date.
- Clear instrument memory.
- Easy to install software available from CD or website.

The bluDock U2CI™ application will operate on Windows XP, Vista and 7\*\*; and Macintosh OSX\*\*\*. If you are running an older operating system, contact the Myron L Company.

A wireless USB adapter (dongle) is included for Mac or PC platforms that do not have built-in Bluetooth\* wireless communication capabilities. If a replacement dongle is required, one can be ordered separately. Order Model: BDDO

**NOTE:** The bluDock module is a fully qualified Bluetooth® 2.1/2.0/1.2/1.1 module +EDR for 2.0 and 2.1.

## LIMITED WARRANTY

All Myron L bluDocks have a Two Year Limited Warranty. Warranty is limited to the repair or replacement of the bluDock only, at our discretion. The Myron L Company assumes no other responsibility or liability.

\* The Bluetooth word mark and logos are registered trademarks of Bluetooth SIG, Inc. and any use of such marks by Myron L Company is under license. Other trademarks and trade names are those of their respective owners.

\*\*™Microsoft

\*\*\*©Macintosh

record #	measurement	value	unit	solution	temp.	date	time
1	COND	.00	uS	H4C3	17	2004.04.17	22:10:42
2	RES	34.7	kOhm	USER[6.35/1.6]	58.5	2005.12.17	18:38:46
3	RES	20	kOhm	USER[3.95/5.8]	50.6	2006.08.24	22:52:51
4	COND	.00	uS	USER[9.65/7.6]	30.7	2006.12.04	5:57:44
5	COND	.00	uS	442	68.6	2006.01.29	7:03:26

Myron L U2CI software screen displaying 5 records

2450 Impala Drive  
Carlsbad, CA 92010-7226 USA  
Tel: +1-760-438-2021  
Fax: +1-800-869-7668 / +1-760-931-9189  
www.myronl.com

**Built On Trust.** Founded in 1957, the Myron L Company is one of the world's leading manufacturers of water quality instruments. Because of our commitment to product improvement, changes in design and specifications are possible. You have our assurance any changes will be guided by our product philosophy: accuracy, reliability, and simplicity.

**MYRON L  
COMPANY**  
Water Quality Instrumentation  
Accuracy • Reliability • Simplicity